

Mounting filters on iAD series

Guide

1.



1. Make sure the rubber sealing is folded inside the filter before inserting it in to the vac.

2.



2. Insert the filter from the bottom of the vac. Make sure the sealing in the bottom of the vac is removed before inserting the filter. The filter is already applied with a sealing.

3.



3. Fold the rubber sealing inside and out over the top of the vac.

4.



4. Make sure the rubber sealing properly folded all the way around the top of the vac.

HTC Sweden AB

Postal address: Box 69, 614 22 Söderköping

Visiting-/delivery address: Klevvägen 7

SE-614 92 Söderköping

Phone: +46 121-294 00. Fax: +46 121-152 12

E-mail: info@htc-sweden.com

